



Hydrometer



The hydrometer floats to the surface when

the alcohol is no longer effective and needs


to be changed.

The hydrometer remains submerged when the alcohol continues to be reusable.

Technical Specifications

Dimensions	25 (W) x 24 (D) x 31 (H) cm 9.8 (W) x 9.4 (D) x 12.2 (H) in	Tank Size	25 (W) x 24 (D) x 20 (H) cm 9.8 (W) x 9.4 (D) x 7.9 (H) in
Weight	2.7 kg 6 lbs	Base Size	23 (W) x 23 (D) x 12 (H) cm 9.1 (W) x 9.1 (D) x 4.7 (H) in
Power Input	100-240VAC, 50-60Hz	Tank Volume	7 L
Rated Power	48 W	Time Control	3, 5, or 10 minutes
















CLEANI with **Tank**^{₽lus} Quick Start Guide

Product Overview












hydrometer in the tank.

ignition sources.




but should not exceed the middle bar of the handle.

Package Contents





Cleaning Process





and evaporation.










After cleaning is completed, remove and dry the applications by applying air to remove any remaining liquid.



Always wear gloves when handling alcohol or uncured resin.

Use UV-filtered lights in your workspace to prevent unintended curing.